



# Lights & Sound Spin 'N Saucer™

## model/modèle/modelo #636

For ages 1 1/2 to 5 years.

Pour enfants de 1 1/2 à 5 ans.

Para los niños 1 1/2 a 5 años.



Register this product at [www.radioflyer.com/register](http://www.radioflyer.com/register) for a chance to win a **Free Radio Flyer product!** (One winner selected every month!)

Thank you for your purchase. If you have any questions or comments, please visit the customer service section of our website:

Merci d'avoir acheté notre produit. Si vous avez des questions ou commentaires, veuillez référer notre site web dans la section de service à la clientèle:

Gracias por su compra. Si tiene preguntas o comentarios por favor visite la seccion, servicio al cliente de nuestro website:

# www.radioflyer.com

Or phone / ou composez le / o llame al 1-800-621-7613

Available weekdays 8:00 a.m. to 5:00 p.m. CST.

Please keep this sheet for future reference.

Disponible sur semaine de 8:00 heures 17:00 heures.

Veillez garder cette feuille comme référence.

De lunes a viernes de 8:00 a.m. a 5:00 p.m. CST.

Por favor retenga esta copia para futura referencia.

Radio Flyer Inc. / 6515 West Grand Ave. / Chicago, IL 60707

fax: 773-637-8874

*The Original Little Red Wagon™ - Since 1917*

### • FCC Statement (U.S. Only)

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- 1.) This device may not cause harmful interference, and
- 2.) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the Limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



**Batteries to be inserted with the correct polarity.**



**Les piles être insérées avec la polarité correcte.**



**Las baterías para ser metidas con la polaridad correcta.**

### CAUTION: To avoid battery leakage

- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire.
- DO NOT mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- DO NOT use rechargeable batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.
- Different types of batteries should not be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Exhausted batteries should be removed from the toy.
- Dispose of batteries safely.
- Do not mix old and new batteries

### ATTENTION: Pour éviter les fuites

- NE PAS incinérer les piles usagées.
- NE PAS brûler les piles.
- NE PAS mélanger des piles alcalines avec des piles standard (carbone-zinc) ou des piles rechargeables (nickel-cadmium).
- NE PAS utiliser des piles rechargeables.
- NE PAS recharger des piles non-rechargeables.
- NE PAS court-circuiter les points de livraison.
- Los tipos diferentes de baterías no se deben mezclar.
- Sólo baterías del tipo mismo o equivalente como recomendado deberán ser utilizadas.
- Las baterías agotadas deberán ser quitadas del juguete.
- Jetez les piles avec précaution.
- Ne pas mélanger piles neuves et anciennes

### PRECAUCIÓN: Para evitar que las pilas se descompongan

- NO incinere las pilas usadas.
- NO exponga las pilas usadas al fuego.
- NO mezcle pilas alcalinas, estándar (zinc carbono) o recargables (níquel cadmio).
- NO utilice pilas recargables.
- No recargue pilas no recargables.
- No haga corto circuito en las terminales.
- Les types différents de piles ne devraient pas être mélangés.
- Seulement les piles de type pareil ou équivalent comme recommandé va être utilisé.
- Les piles épuisées devraient être enlevées du jouet.
- Elimine las pilas de manera segura.
- No mezcle pilas viejas y nuevas

**Requires 3 "AAA" (called LR3 in some countries) batteries. Install new batteries as shown in the polarity diagram(+/-) inside battery compartment.**

Fonctionne avec 3 piles "AAA" (LR3). Mettre de nouvelles piles comme indiqué sur le diagramme de polarité (+/-) à l'intérieur du compartiment.

Funciona con pilas 3 AAA-LR3. Coloque las pilas nuevas siguiendo el diagrama de polaridad (+/-) que se muestra dentro del compartimento para las baterías.